


## 2006 Acura MDX

2003-06 ENGINE Ignition System - MDX

### 2003-06 ENGINE

### Ignition System - MDX

## COMPONENT LOCATION INDEX




**Fig. 1: Locating Ignition System Components**  
Courtesy of AMERICAN HONDA MOTOR CO., INC.

## CIRCUIT DIAGRAM



**TROUBLESHOOTING INFORMATION** ), and check for DTCs. If a DTC is present, diagnose and repair the cause before inspecting the ignition timing.

2. Start the engine. Hold the engine at 3,000 rpm without (in Neutral) until the radiator fan comes on, then let it idle.
3. Check the idle speed (see **IDLE SPEED INSPECTION** ).
4. Select "SCS" mode using the HDS.
5. Connect the timing light to the service loop.




G03639160

**Fig. 3: Connecting Timing Light To Service Loop**  
Courtesy of AMERICAN HONDA MOTOR CO., INC.

6. Aim the light toward the pointer (A) on the timing belt cover. Check the ignition timing under a no load condition (headlights, blower fan, rear window defogger, and air conditioner are turned off).

**Ignition Timing:  $10^{\circ} \pm 2^{\circ}$  BTDC (RED mark (B)) at idle in Park or Neutral**



G03639161

**Fig. 4: Aiming Light Toward Pointer On Timing Belt Cover**  
Courtesy of AMERICAN HONDA MOTOR CO., INC.

7. If the ignition timing differs from the specification, check the cam timing. If the cam timing is OK, update the powertrain control module (PCM) if it does not have the latest software (see **PCM UPDATING AND SUBSTITUTION FOR TESTING** ), or substitute a known-good PCM (see **HOW**

## 2006 Acura MDX


2003-06 ENGINE Ignition System - MDX

**TO SUBSTITUTE THE PCM** ), then recheck. If the ignition system works properly, replace the original PCM (see **PCM REPLACEMENT** ).

8. Disconnect the HDS and the timing light.

### IGNITION COIL REMOVAL/INSTALLATION

1. Remove the intake manifold cover (A) and ignition coil cover (B).




G03639162

**Fig. 5: Removing Intake Manifold Cover And Ignition Coil Cover**  
Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. Disconnect the ignition coil connector (A), then remove the ignition coils (B).





G03639163

**Fig. 6: Disconnecting Ignition Coil Connector**  
Courtesy of AMERICAN HONDA MOTOR CO., INC.

3. Install the ignition coils in the reverse order of removal.

## IGNITION COIL RELAY CIRCUIT TROUBLESHOOTING

1. Check the No. 46 (15 A) fuse in the under-hood fuse/relay box and No. 8 (15 A) fuse in the under-hood subfuse box.

**Is the fuse OK?**

**YES** - Go to step 2.

**NO** - Replace the fuse.

2. Remove the ignition coil relay from the relay block, and test it (see **POWER RELAY TEST** ).


**Is the relay OK?**

**YES** - Go to step 3.

**NO** - Replace the ignition coil relay.

3. Measure the voltage between ignition coil relay 4P socket terminal No. 1 and body ground.

## **IGNITION COIL RELAY 4P SOCKET**



**Terminal side of female terminals**

**G03639164**

**Fig. 7: Measuring Voltage Between Ignition Coil Relay 4P Socket Terminal No. 1 And Body Ground**

**Courtesy of AMERICAN HONDA MOTOR CO., INC.**

**Is there battery voltage?**


**YES** - Go to step 4.



**NO** - Repair an open in the wire between ignition coil relay 4P socket terminal No. 1 and the under-hood subfuse box.

4. Measure the voltage between ignition coil relay 4P socket terminal No. 4 and body ground.

## IGNITION COIL RELAY 4P SOCKET



**Terminal side of female terminals**

**G03639165**

**Fig. 8: Measuring Voltage Between Ignition Coil Relay 4P Socket Terminal No. 4 And Body Ground**

Courtesy of AMERICAN HONDA MOTOR CO., INC.


**Is there battery voltage?**

**YES** - Go to step 5.

**NO** - Repair an open in the wire between ignition coil relay 4P socket terminal No. 4 and the under-hood fuse/relay box.

5. Check for continuity between ignition coil relay 4P socket terminal No. 2 and No. 1 ignition coil 3P connector terminal No. 3.

## IGNITION COIL RELAY 4P SOCKET



G03639166

**Fig. 9: Checking Continuity Between Ignition Coil Relay 4P Socket Terminal No. 2 And 1 Ignition Coil 3P Connector Terminal No. 3**

Courtesy of AMERICAN HONDA MOTOR CO., INC.


**Is there continuity?**

**YES** - Go to step 6.

**NO** - Repair an open in the wire between ignition coil relay 4P socket terminal No. 2 and ignition coil 3P connector terminal No. 3.

6. Check for continuity between ignition coil relay 4P socket terminal No. 3 and body ground.

## IGNITION COIL RELAY 4P SOCKET



Terminal side of female terminals

G03639167

**Fig. 10: Checking Continuity Between Ignition Coil Relay 4P Socket Terminal No. 3 And Body Ground**

Courtesy of AMERICAN HONDA MOTOR CO., INC.

**Is there continuity?**

**YES** - Repair a short in the wire between ignition coil relay 4P socket terminal No. 3 and the PCM (B12).

**NO** - Go to step 7.

## 2006 Acura MDX


2003-06 ENGINE Ignition System - MDX

7. Turn the ignition switch OFF.
8. Connect the Honda Diagnostic System (HDS) to the data link connector (DLC) (see step 2 on **GENERAL TROUBLESHOOTING INFORMATION** ). Turn the ignition switch ON (II), and jump the SCS line with the HDS, then turn the ignition switch OFF.

**NOTE:** This step must be done to protect the powertrain control module (PCM) from damage.

9. Disconnect PCM connector B (56P).
10. Check for continuity between ignition coil relay 4P socket terminal No. 3 and PCM connector terminal B12.

### IGNITION COIL RELAY 4P SOCKET



Terminal side of female terminals


**Fig. 11: Checking Continuity Between Ignition Coil Relay 4P Socket Terminal No. 3 And PCM Connector Terminal B12****Courtesy of AMERICAN HONDA MOTOR CO., INC.****Is there continuity?**

**YES** - The system is OK at this time. Check for loose or poor connections at the ignition coil relay and the PCM (B12).

**NO** - Repair an open in the wire between ignition coil relay 4P socket terminal No.3 and the PCM (B12).

**SPARK PLUG INSPECTION**

1. Inspect the electrodes and ceramic insulator.
  - Burned or worn electrodes may be caused by:
    - Advanced ignition timing
    - Loose spark plug
    - Plug heat range too hot
    - Insufficient cooling
  - Fouled plug may be caused by:
    - Retarded ignition timing
    - Oil in combustion chamber
    - Incorrect spark plug gap
    - Plug heat range too cold
    - Excessive idling/low speed running
    - Clogged air cleaner element
    - Deteriorated ignition coils



G03639169

**Fig. 12: Inspecting Electrodes And Ceramic Insulator**  
Courtesy of AMERICAN HONDA MOTOR CO., INC.

2. If the spark plug electrode is dirty or contaminated, clean the electrode with a plug cleaner.


**NOTE:**

- Do not use a wire brush or scrape the iridium electrode since this will damage the electrode.
- Use a chemical cleaner such as Carb Spray to clean contamination on the electrode.
- When using a sand blaster spark plug cleaner, do not clean for more than 20 seconds to avoid damaging the electrode.

3. Do not adjust the gap (A) of iridium tip plugs; replace the spark plug if the gap is out of specification.

**Electrode Gap**

**Standard (New): 1.0-1.1 mm (0.039-0.043 in.)**



**Fig. 13: Checking Plug Cleaner**

Courtesy of AMERICAN HONDA MOTOR CO., INC.




4. Replace the plug at the specified interval or if the center electrode is rounded (A). Use only the listed spark plugs.

**Spark Plugs**

**NGK: IZFR5K11**

**DENSO: SKJ16DR-M11**



G03639171

**Fig. 14: Replacing Plug At Specified Interval Or If Center Electrode Is Rounded**

<b>2006 Acura MDX</b>
2003-06 ENGINE Ignition System - MDX

**Courtesy of AMERICAN HONDA MOTOR CO., INC.**

5. Apply a small amount of anti-seize compound to the plug threads, and screw the plugs into the cylinder head, finger-tight. Then torque them to 18 N.m (1.8 kgf.m, 13 lbf.ft).